

Enhancing power production without safety concessions in cold climates

- early ice prediction by sensor fusion of surface and high-precision wind data

Theresa Loss¹, Katrin Ritter², Michael Moser¹

- 1 ...eologix sensor technology gmbh
- 2...ROMO Wind / Nabla Wind Hub

© eologix sensor technology gmbh 2022, All rights reserved.
The content of this presentation is proprietary and confidential information of eologix sensor technology gmbh. It is not intended to be distributed to any third party without the written consent of eologix sensor technology gmbh.



Problem Statement



No ice

- No meteorological icing conditions
- Optimal performance

Early-stage ice

- Close to meteorological icing conditions (e.g. temperature ~0°C)
- Aerodynamics
- Production losses

Ice

- Meteorological icing conditions
- Severe icing
- Safety stop



INTRODUCTION

MEASUREMENT SYSTEM

POWER CURVE & ICING

MEASURE FOR EARLY-STAGE ICE

RESULTS

Introduction



- Thin layers of icing decrease the aerodynamic performance of the blades
 - → Stall
 - Reduced output power
- > A variety of approaches exists to prevent safety hazards due to icing
- But: the detection of early-stage ice events is still challenging
 - Minimum mass of ice needed for vibration-based systems

NEW APPROACH:

Measurement of early-stage icing (MESI)

= intermittent stage between pre-icing and operational icing

Close the gap between meteorological methods and commercial ice detection methods

Introduction



Advantages of MESI:

Optimise the activation of the anti-icing system:

- → increase power production
- → prevent safety-stops


Separate power losses due to early-stage icing from other deviations (e.g. mechanical faults).

Measurement System



Eologix ice detection + ROMO Wind measurements + SCADA power output

Eologix ice detection



Eologix & iSpin - Introduction



- 2 ROMO Wind /Nabla Wind Hub iSpin Technology
 - Ultrasonic anemometer
 - > Installation at the hub
 - Measurements taken in front of the rotor
 - Measurement of wind speed, yaw errors and wind inclination angles
 - > 10 Hz data
- 3 SCADA data
 - > Turbine power output




iSpin sensor mounted at the hub (Picture courtesy of ROMO Wind).

Power Curve & Icing




> Eologix ice level per sensor



Power Curve & Icing



> Power curve and correspondence to eologix ice levels



Measure for early-stage ice (MESI)




- Combination of several features per sensor
 - Temperature
 - Feature 1: "Activity Feature", 6 different levels
 - Feature 2: "Icing Feature", 4 different levels
- MESI (per sensor):
 - > Temperature below 3°C
 - Feature 1: member of levels ≥ 4
 - > Feature 2: member of levels 1,3,4
- MESI (combined for all sensors):
 - > Early-stage ice detected for more than 50% of sensors

Measure for early-stage ice (MESI)




> Feature 1



Measure for early-stage ice (MESI)




> Feature 2






> MESI per sensor






- > Overall MESI
 - > Early-stage ice detected for more than 50% of sensors



Power Curve & Icing





> Power curve with SCADA data and iSpin wind measurements





> Detect deviations from the power curve








Production losses for a test turbine in France:

- 3 months (01/12/2020 28/02/2021)
- location in southern France

Production losses due to ...

- > Ice: 4.5 MWh
- > Early-stage ice: 7.2 MWh
- > Other reasons: 17.1 MWh



Summary



- Combination of eologix ice measurements, iSpin wind measurements and SCADA power data
- MESI developed based on eologix ice and temperature measurements on the blades
- Analysis of power curves under icing conditions
- Production losses due to early-stage ice detected on an operational turbine

Benefits of MESI:

- + Detect early-stage ice
- +Optimise blade heating
- + Prevent production loss
- + Prevent foreseeable standstills
- + Distinguish between icing and other causes (e.g. blade damage, mismatch of turbine settings etc.)



ANY QUESTIONS?

Get in touch with us. We are here for you.



office@eologix.com



+43 316 931215 100



Kratkystrasse 2, 8020 Graz Österreich